




COMMERCIAL GAS DRYER

MODELS:

CGD9050AW1 (White)

TOP AND CONSOLE PARTS




Literature Parts

TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	16	8316526	777 Lock and Key, Complete	32	3351136	Assembly, Service Door
	W10726005	Installation Instruction	17	W10139046	Nut	33	W10166307	Harness, Communication
	W10882797	Tech Sheet	18		Hinge & Pin Assembly	34	W10166308	Harness, Meter Case
2		Top		8565018	White	35	W10137448	Cushion, Meter Case
	W10137411	White	19	342055	Screw	36	3349065	Bolt
3	W10846438	Harness, Main	20	3347825	Plate, Mounting	37	W10156125	Cam, Commercial Lock
4	W10779120	Console (Outer)	21	98445	Screw	38	W10198147	Push Button
5	W10135255	Switch, Membrane & Backer Plate	22	W10137445	Bracket - Top Panel, Left	39	W10334890	Fascia-Console
6	8565237	Bracket, Console	23	3390647	Screw	40	W10712874	Fascia Dispenser
7	W10189075	Washer, Brass	24	W10137444	Bracket - Top Panel, Right	41	385421	Funnel, Coin
8	W10532923	Ground-Jumper, Tab	25	W10171132	Meter Case	42	3400029	Nut
9	W10187276	Seal, Console	26	W10267645	Cover, Display	43	3954761	Plate, Adapter
10	337686	Screw	27	W10137457	Screw	44	8318517	Bolt, Slide Mechanism
11	3390647	Screw	28	W10131838	Switch, Vault Service Door	45	W10198126	Coin Slide (Vertical 14)
12	W10137427	Console (Inner)	29	W10133508	Bracket, Service Switch		W10547316	Coin Slide (Vertical 8)
13	W10719682	User Interface	30	W10139210	Screw	46	8316525	Money Box W/Lock
14	489136	Screw	31	W10211244	Wire, Harness Sensor Switch			
15	W10189313	Insert						


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8317339	Cover, Terminal Block	20	W10137398	Stop, Top Panel	41	W10131839	Transformer
2	3390814	Screw	21	8563727	Bracket, Control	42	98129	Screw
3	W10773242	Screw	22	8580015	Ramp, Door	43	3390647	Screw
4		Panel, Side	23	8565122	Strike, Door	44	3387242	Seal, Front Panel
	W10542714	White	24	8539892	Wire, Motor To Belt Switch	45	3393657	Restrainer, Belt
5	8564010	Assembly, Switch and Actuator	25	8565046	Base, Cabinet	46	W10166305	Control Board
6	8519459	Clip, Toe Panel	26	8565059	Panel, Rear			Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
7	8318396	Seal, Foam	27	W10396034	Assembly, Motor 60 HZ.	47	W10470674	Kit, 4-Way Venting
8	3392100	Foot, Dryer	28	3405160	Belt, Drive (Blower Wheel)	48		Plug, Multivent
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	29	3394341	Pulley, Motor		W10404617	White
9	660658	Clamp, Motor	30	W10131172	Belt, Drive	49	W10354249	Plate, Cover
10	W10446781	Spring, Idler	31	8529757	Bracket, Burner	50	W10416072	Elbow
11	3389420	Screw	32	W10135695	Bracket, Motor	51	8563748	Pipe, Exhaust
12	8533971	Screw	33	3401401	Cord, Power	52	W10331278	Pipe, Exhaust (Short)
13	W10344192	Assembly, Idler	34	W10155571	Switch, Assembly	53	8563747	Pipe, Exhaust (Medium)
14	3978776	Bracket, Gas Pipe	35	693995	Screw	54	8563749	Pipe, Exhaust (Long)
15	8564011	Bracket, Switch	36		Panel, Front	55	696392	Hose Clamp
16	W10167613	Wire, Belt Switch		W10549665	White	56	W10344699	Collar, Duct
17	343641	Screw	37	3357011	Screw	57	488729	Screw
18	3391943	Boot, Foot	38	8565043	Plug, Front Panel			
19	W10350910	Assembly, Door Switch	39	W10836094	Motor, Sound Pad			
			40		Toe Panel			
				8540621	White			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	15	693995	Screw	30	3387230	Screw
2	3390647	Screw	16	W10001120	Nut, Hex (Left Hand Thread)	31	338906	Sensor, Radiant
3	W10153413	Door, Lint Screen	17	W10080170	Bulkhead, Rear	32	3401707	Jumper, Wire
4	3392519	Fuse, Thermal (91C)	18	3387459	Washer	33	W10153409	Baffle, Drum
5	3394346	Assembly, Air Duct	19	W10359272	Shaft, Drum Roller - Left Hand Thread	34	8565061	Bulkhead, Front
6	697813	Seal, Outlet Housing	20	W10512946	Washer, Tri Ring	35	8578825	Bracket, Drum Light
7	697814	Seal, Drum Front	21	W10314171	Roller, Support	36	W10153412	Grille, Outlet
8	3934666	Nut, Hex	22	8563728	Pipe, Exhaust	37	W10349492	Wheel, Blower
9		Lint Screen	23	W10153423	Assembly, Outlet Housing	38	8573713	Cut-Off, Thermal
	W10596627	White	24	489463	Screw	39	3394986	Spring, Lint Screen Door
10	3402841	Lens, Drum Light	25	W10549246	Assembly, Drum (Complete)	40	697770	Seal, Plate Cover
11	359625	Screw	26	W10219342	Screw	41	695240	Screw
12	8572105	Clip, Exhaust	27	W10521118	Seal, Drum	42	8577274	Thermistor
13	8533971	Screw	28	8573824	Funnel, Burner	43	3391912	Thermostat, Hi Limit
14	8066168	Assembly, Lint Duct	29	90767	Screw	44	8544362	Housing, Blower
						45	W10344699	Collar, Duct

BURNER ASSEMBLY PARTS


USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASSES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10135231	Burner Assembly (60 Hz)	12	694538	Bracket, Coil	24	3387561	Clamp, Pipe
2	688617	Tube, Burner	13	694540	Coil, 60 Hz. (2 Terminal) (Main)			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)	W10135245		Conversion Kit (Type 1 and 2) to Type L.P.G.
4	686590	Ignitor	15	694424	Leak, Limiter			
5	3393909	Screw	16	694423	Screw, Regulator Adjustment			
6	343641	Screw	17	694422	Spring, Regulator			
7	3389871	Base, Burner	18	239822	Plug, Pipe			
8	3387057	Screw	19	697441	Valve, Gas			
9		Orifice, Burner	20	233076	Nut, Compression			
	234870	Type 1 (Natural)	21	3393767	Pipe, Tail			
	234868	Type 4 (Propane)	22	W10110395	Pipe, Gas Supply			
10	W10141728	Valve, Gas (60 Hz - Complete)	23	3389889	Bracket, Support			
11	694421	Screw, Coil						

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Label-Hinge Hole
	W10256915	White
2	W10304672	Assembly, Door Hinge
3	W10283424	Door, Intermediate Stationary
4	9742177	Screw
5	W10163915	Seal, Door
6	8579663	Seal, Window
7	W10215754	Handle, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10159996	Screw
9	3393258	Screw
10	W10564641	Assembly, Inner Door
11	355515	Screw
12		Screen, Door (Not Serviceable)
13	W10286878	Window
14	690081	Assembly, Door Catch
15	8519354	Retainer, Window

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10215742	Door, Outer Ring
17	3357011	Screw
18	8519356	Retainer, Window (Upper)
19		Door, Outer
	W10215753	White
20	W10363674	Door, Inner
21	8565087	Screw

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8529894	Kit, Hold Down
	80047	Kit, Dryer Repair
	8316524	Kit, Chute Decal